



MOTORCYCLE SADDLE BAGS

GENERAL FEATURES AND ADVICE TO USERS

The saddles come with semi rigid plastic sheet system. These should be inserted properly into the fabric loops provided to maintain the bags shape.

Always load the saddles evenly.

The two opposed central straps should be fastened together and mounted underneath the seat (Figure 1). Then the Velcro straps provided should be fastened together well enough and mounted over or under the seat to allow the best secure fit to your motorcycle (Figure 2). The minimum Velcro overlap should be 16cms. Make sure the saddles sit tight against the side of the motorcycle and do not sag. There are also two adjustable cam buckle webbing straps which should be used to hold the saddles firmly by passing them through the attached D rings on the saddle and correct part of the motorcycle (Such as dedicated luggage hooks and not to the indicators) Use the six bungies provided with the saddles to secure any remaining attachment points on the bags to an appropriate part of the motorcycle. If you think the bungee length is not correct then you might need to purchase bungies of correct length depending on the kind of motorcycle you have to complete a secure attachment. The saddles should not be free to move as they may cause injury, rub the paint off or burn if in contact with the exhaust for a long time.

The saddles can be secured from the top with webbing buckle straps to prevent sagging when expanded and carrying extra load.



Figure - 1



Figure - 2

LOADING: Make sure the luggage is installed and loaded evenly and within the stated maximum capacity and weight limits. Do not carry sharp, pointed or flammable objects in the luggage. Always keep heavy articles at the bottom.

FITMENT: The luggage should be securely attached to the motorcycle and should be mounted clear off moving parts and sources of heat such as engine exhaust systems.

Make sure the motorcycle is clean and smooth while mounting the luggage to avoid any possibility of abrasion.

PRODUCT CARE & USAGE: To clean any dirt off your luggage use a wet sponge or cloth with a mild detergent on it. Do not use harsh chemicals. Extra precaution has to be taken with luggage that uses magnetic mountings as it might affect items containing magnetic data such as credit cards, film etc.

WARRANTY: All luggages are warranted to the original purchaser to be free of manufacturing defects for a period of 12 months. This warranty however does not extend to ancillary parts such as rain covers, bungee cords, buckles and rivets. Our liability extends to material and workmanship only.

This warranty is void if product failure is due to misuse, abuse, neglect, accident and improper installation. Also not covered are consequential damages, incidental damages or damage to person or property due to above factors. All warranties are covered only by an original proof of purchase. Your sale contract is with the dealership where the product was purchased and therefore it has to be returned there.